

PHOTOGRAPHS

PHOTOGRAPH #1



BUILDING 6 SECTION B

Contractor installing 15/32" exterior rated plywood sheathing with 8d common nails spaced at 4" on-center.

PHOTOGRAPH #2



BUILDING 6 SECTION C

Contractor installing 15/32" exterior rated plywood sheathing with 8d common nails spaced at 4" on-center.

PHOTOGRAPH #3



**BUILDING 6
SECTION C**

Contractor installing 15/32" exterior rated plywood sheathing with 8d common nails spaced at 4" on-center.

PHOTOGRAPH #4



**BUILDING 6
SECTION B**

BASF Urethane Sealant was applied to gaps larger than 1/8".

PHOTOGRAPH #5



**BUILDING 6
SECTION C**

BASF Urethane Sealant was applied to gaps larger than 1/8".

PHOTOGRAPH #6



**BUILDING 6
SECTION C**

BPA galvanized nails .113\" x 2-3/8\" were used for sheathing installation.

PHOTOGRAPH #7



**BUILDING 6
SECTION C**

Nails and staples to be removed prior to sheathing installation.

PHOTOGRAPH #8



**BUILDING 6
SECTION C**

Contractor applied BASF sealant to gap adjacent to balcony door frame and did not tool flush.

Contractor to remove cured sealant bead, reapply, and tool smooth.

PHOTOGRAPH #9




**BUILDING 6
SECTION C**

Contractor applied BASF sealant to gap adjacent to balcony door frame and did not tool flush.

Contractor to remove cured sealant bead, reapply, and tool smooth.

PHOTOGRAPH #10



**BUILDING 6
SECTION C**

BASF Urethane Sealant to be applied to gaps larger than 1/8".

PHOTOGRAPH #11



**BUILDING 6
SECTION B**

Contractor completely removed beehive and debris.

PHOTOGRAPH #12



**BUILDING 6
SECTION B**

Contractor added missing TSP strap from stud to top plate.

PHOTOGRAPH #13



**BUILDING 6
SECTION B**

Contractor added intermediate stud where the studs were spaced greater than 16" on-center.

PHOTOGRAPH #14



**BUILDING 6
SECTION F**

Contractor covered sealant to paint window trim before sealant fully cured. The plastic covering has embedded in the sealant.

Contractor to remove, clean, and reapply sealant at this window.

PHOTOGRAPH #15



**BUILDING 6
SECTION F**

Contractor covered sealant to paint window trim before sealant fully cured. The plastic covering has embedded in the sealant.

Contractor to remove, clean, and reapply sealant at this window.

PHOTOGRAPH #16



**BUILDING 6
SECTION F**

Contractor covered sealant to paint window trim before sealant fully cured. The plastic covering has embedded in the sealant.

Contractor to remove, clean, and reapply sealant at this window.

PHOTOGRAPH #17



**BUILDING 6
SECTION F**

Contractor applied two coats of paint to window trim and balcony edges.

PHOTOGRAPH #18



**BUILDING 6
SECTION F**

Sealant applied to kick-out flashing and excess to be trimmed.

PHOTOGRAPH #19



**BUILDING 6
STORAGE**

Construction materials are not covered from weather and protected from theft.

Contractor to cover and protect building material on-site.

PHOTOGRAPH #20



**BUILDING 3
SECTION B**

Contractor applied MasterSeal NP-1 Sealant to small hole in window trim.

PHOTOGRAPH #21



**BUILDING 3
SECTION H**

Contractor applied sealant around pipe at wall penetration.